

Divider Rails

Why Use a Divider Rail?

1. Muttons or other obtrusions that interfere with louver movement
2. Increase panel stability

Divider Rail is required on panels over 106"

Measuring for Divider Rails

Window Size Measurements

Record measurement from the bottom of window opening to the center of the rail

Net Panel Measurements

Record measurement from the bottom of the panel to the center of the rail

ODF Measurements

Record measurement from the bottom of the frame to the center of the rail

NOTE: CENTER LINE LOCATION OF DIVIDER RAIL MAY VARY UP OR DOWN BY A MAXIMUM OF 1

Divider Rail Size

Divider Rails can be manufactured at any height so as to match existing window mullions. Unless requested otherwise they will be the standard sizes are listed below.

	<i>3 3/8" Divider Rail</i>	<i>4 3/8" Divider Rail</i>
<i>2 1/2" Louver</i>		Standard Size
<i>3 1/2" Louver</i>	Standard Size	
<i>4 1/2" Louver</i>		Standard Size

