

# Frame Assembly for *pre-hung shutters*

*Note: For safe shipping most pre-hung shutters will be knocked down*

1. Identify and layout frame pieces, face side down, on a non marring work surface
2. Place a small amount of carpenters wood glue on each frame joint.
3. Place Hoffman Key round side down in each joint
4. Drive Hoffman Key in with a hammer or rubber mallet.
5. For maximum strength, use a pneumatic nail gun to further secure corners.

