

Louver Clearance Diagram

Louver clearance is critical for inside mount shutters.

When measuring, be sure to account for mullions or locks that may interfere with pivot of louvers

