

# Net Panel Size

*SMI recommends net panel size measurements for UNFRAMED PANELS ONLY*

## INSIDE MOUNT

1. Measure window depth for louver clearance
2. Measure window width and height in several places
3. Check for square by measuring on the diagonal, if diagonals are a 1/2" different SMI suggests recording smaller measurements.

## OUTSIDE MOUNT

NA

Framed Openings: SMI will take net panel sizes and add for hinge gaps and frames

Unframed Openings: SMI will build shutter to exact "net panel" measurements provided